

Electric wine opener - battery operated

SKU: TP1P911.411

Categorie:

Disponibilitate: În stoc (3892)

This battery operated electric corkscrew uncorks a bottle of wine with the push of a button. Including 4 AA batteries. Packed in a giftbox.

